

## Recessed Steps

|               |   |
|---------------|---|
| <b>SP3001</b> |   |
|               | <p style="font-size: 1.2em; font-weight: bold;">SP3001</p> <p style="font-size: 1.1em; font-weight: bold;">Recessed Step</p> <p>1) Finish: Face flange is polished. Inside is bead-blasted.</p>             |
| <b>SP3002</b> |   |
|               | <p style="font-size: 1.2em; font-weight: bold;">SP3002</p> <p style="font-size: 1.1em; font-weight: bold;">Recessed Step</p> <p>1) Finish: Face flange is polished. Inside is bead-blasted.</p>             |
| <b>SP3003</b> |   |
|               | <p style="font-size: 1.2em; font-weight: bold;">SP3003</p> <p style="font-size: 1.1em; font-weight: bold;">Recessed Step<br/>6" Deep</p> <p>1) Finish: Face flange is polished. Inside is bead-blasted.</p> |

